

# L44-L66-Wall Installation Instructions


## Overview

### WARNINGS

- This product must be installed in accordance with all applicable codes by a person familiar with the product.
- Each fixture must be **properly supported** during install.
- **DO NOT** join fixtures on the floor prior to lifting, or damage will occur.
- **Before beginning installation**, review our complete list of warnings



**MOBERN**  
LIGHTING



# L44-L66-Wall Installation Instructions

## Preparation - Tools/Parts Identification



MOBERN  
LIGHTING

### A. Identify Fixtures

Mobern LED


PART# 44WSFXXLTXXWXXXXLDMVXXKWH

VOLTAGE: 120-277, 50/60HZ  
WATTAGE: XX MAX  
FLUX: XXXX LUMENS

CCT: XXXX  
DATE CODE: XX/XX/XX  
TYPE: XX

- Use labels found on the box and inside fixture bodies to identify bodies.
- **NOTE:** Locations of labels can vary.
- Remove all fixtures from their boxes.
- Organize fixtures based on their labels at the install location.


### B. Tools Needed




Screwdrivers



3/4" Drill Bit



Drill



Safety Glasses

- Always use proper safety equipment when installing fixtures.
- Tools shown are recommended for standard install. Tools needed may vary based on actual install location conditions.

### C. Identify Parts



44/66 Wall Mount Fixture  
(Provided)



Mounting Screw W/ Anchor  
(By Others)

- Read entire install instructions before beginning installation.
- Unpack all components and arrange in order of install steps.
- For help with installation, please contact us at [www.mobern.com](http://www.mobern.com) or call us at (972) 247-3171.


# L44-L66-Wall Installation Instructions

## Step 1 - Prepare For Install




**MOBERN**  
LIGHTING

### A. Remove The Lens & Gear Tray




- Carefully insert a flat tip screwdriver, and use a gentle prying motion to remove lenses.
- Remove the gear tray as shown. Set the lens and gear tray aside in a safe location.

### B. Remove 7/8" Knockout



- Using a gentle, prying motion, remove the 7/8" knock out from the desired location..

### Items Used In This Step



Flat Tip Screwdriver


# L44-L66-Wall Installation Instructions

## Step 2 - Wire The Fixture




MOBERN  
LIGHTING

### A. Drill Hole For Wiring



- Using a 3/4" bit, drill a hole to allow supply wiring to pass thru.
- **Note:** Use caution when drilling as to not damage components inside of wall.

### B. Connect The Wiring




WIRING LEGEND		
Black	Hot	Line Voltage
White	Neutral	Line Voltage
Green	Ground	
Gray	Dimming	0-10V DC
Violet	Dimming	0-10V DC

- Wire the fixture to the incoming supply. Refer to the wiring legend above as needed.
- **Note:** Use UL approved connectors only. Follow all local, state and national codes

### Items Used In This Step



3/4" Drill Bit



Drill


# L44-L66-Wall Installation Instructions

## Step 3 - Install The Fixture




**MOBERN**  
LIGHTING

### A. Mount The Fixture




- Press the fixture firmly to the wall.
- Secure the body to the mounting surface using anchored mounting screws (by others).

### B. Replace Components




- Install the gear tray back in to the fixture as shown above.
- Reinstall the lens by lining up with the fixture and gently press, causing the lens to snap in.
- Install is now complete.

### Items Used In This Step



Drill



Mounting Screw W/ Anchor  
(By Others)